

THE ULTIMATE SANDPAPER GRIT GUIDE

Not because you need it. But just in case.

UP TO 36

- 1ST ROUND ON HARDWOOD FLOOR
- ### 40 - 60
- CLEAR 1 LAYER OF FINISH OR DEBRIS
 - HEAVY STRIPPING/SANDING

- REMOVE MAJOR RUST ON METALS
- LEVEL AND SHAPE WOOD
- LEAVES BEHIND SCRATCHES

80

- VARNISH OR FINISH REMOVAL PREP
- ### 100 - 120
- CLEAN PLASTER
 - REMOVE SCRATCHES
 - REMOVE WATER STAINS FROM WOOD

- REMOVE SMALL IMPERFECTIONS

150 - 220

- 1ST ROUND ON HARDWOOD FLOOR
- BEFORE STAIN, SEALER, OR PRIMER
- REMOVE LIGHT METAL CORROSION

240

- BETWEEN FINISH COATS

- REMOVE RAISED WOOD FIBERS

320 - 360

- MINIMUM GRIT FOR BEST METAL FINISH

- REMOVE LUSTER OR SHEEN
- REMOVE MINOR BLEMISHES

400 - 600

- FINAL FINISH ON WOOD

800 AND UP

- POLISHING FINAL FINISHES & METALS

GRITS ARE LIKE GOALS:
START SMALL

xoxo Blaire